



HP Point of Sale (POS) Peripherals Configuration Guide – HP Peripherals OPOS Name

Document Version 3.30
January 2011

© Copyright 2007-2010 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

Microsoft, MS-DOS, Windows, WEPOS, POSReady and Windows NT are trademarks of Microsoft Corporation in the U.S. and other countries.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

HP Point of Sale (POS) Peripherals Configuration Guide – HP Peripherals OPOS Name
Document Version 3.30.0003

January 2011

1 List of Peripherals and General Information

1.1.1 Hardware

The following table shows the connection type (i.e. USB / Serial, etc.) for the peripherals:

HP Product Name	Description	Connector Type
HP Cash Drawer	Cash Drawer	RJ45 from printer.
HP Flip Top Cash Drawer	Flip Top Cash Drawer	RJ45 from printer.
HP USB POS Keyboard	POS keyboard with touchpad.	USB
HP USB POS Keyboard with MSR	POS keyboard with touchpad and integrated MSR.	USB
HP USB Receipt Printer	Thermal Printer	Serial / USB USB – Powered USB 24V
HP USB Receipt Printer (Hybrid Printer MICR)	Hybrid Printer MICR	USB – Powered USB 24V
HP USB Receipt Printer (Hybrid Printer MICR with Imager)	Hybrid Printer MICR with Imager	USB – Powered USB 24V
HP USB Barcode Scanner	Scanner	USB
HP USB Imaging Barcode Scanner	HP USB Imaging Barcode Scanner	USB
HP USB Mini-MSR	Magnetic Strip Reader (MSR)	USB
HP L5006tm	Touch Screen	VGA / USB or Serial
HP L5009tm	Touch Screen	VGA / USB
HP ap5000 MSR (integrated)	HP ap5000 MSR	Serial
HP ap5000 Line Display (VFD)	HP ap5000 VFD	Serial – Powered 5V

2 OPOS Name for HP Point of Sale Peripherals

The following are the OPOS logical names for the HP Point of Sale Peripherals:

Device	OPOS Logical Name
HP POS Pole Display	HP POS Pole Display
HP ap5000 Line Display (VFD)	HPap5000LineDisplay
HP USB Barcode Scanner	HP_USBSCANNER (underscore between each word)
HP Imaging Barcode Scanner	HPImageScanner
HP USB Mini-MSR	HPUSBMiniMSR
HP ap5000 MSR	HPap5000MSR
HP POS Keyboard	HPPOSKeyboard
HP POS Keyboard with MSR	HPKBMSR
HP CheckScanner	A776
HP MICR	A776
HP USB Receipt Printer (A794)	A794
HP Cash Drawer or Flip Top Cash Drawer attached to (A794)	A794-1 (first cash drawer or first flip top cash drawer)
HP Cash Drawer or Flip Top Cash Drawer attached to (A794)	A794-2 (second cash drawer or second flip top cash drawer)*
HP USB Receipt Printer (A799) – USB and Serial model(s) of the printer	A799
HP Cash Drawer or Flip Top Cash Drawer attached to (A799)	A799-1 (first cash drawer or first flip top cash drawer)
HP Cash Drawer or Flip Top Cash Drawer attached to (A799)	A799-2 (second cash drawer or second flip top cash drawer)*
HP USB Receipt Printer (A776 - Hybrid Printer MICR)	A776
HP Cash Drawer or Flip Top Cash Drawer attached to (A776)	A776-1 (first cash drawer or first flip top cash drawer)
HP Cash Drawer or Flip Top Cash Drawer attached to (A776)	A776-2 (second cash drawer or second flip top cash drawer)*
HP USB Receipt Printer (A776 - Hybrid Printer MICR with Imager)	A776
HP Cash Drawer or Flip Top Cash Drawer attached to (A776 - Hybrid Printer MICR with Imager)	A776-1 (first cash drawer or first flip top cash drawer)
HP Cash Drawer or Flip Top Cash Drawer attached to (A776 - Hybrid Printer MICR with Imager)	A776-2 (second cash drawer or second flip top cash drawer)*

* Requires a Y-Adapter and the second cash drawer requires a separate cash drawer cable.