

Configuration rapide pour Metrologic MS6220 (C17) Pulsar Wedge

Restore Default Settings



Enter Setup

• Activate and Select Keyboard Type



*



2



AZERTY