

# Configuration rapide pour douchette Zebex



Start of Configuration



RESET



USB



PC/AT

OU



French



French



Send number as keypad data



End of Configuration